

***PRECISIONSKIVED™***

***PTFE Film Tape  
Silicone Adhesive***

PRECISIONSKIVED™ is pure unsupported virgin polytetrafluoroethylene (PTFE) film with all the characteristics of our PTFE coated fiberglass tape plus the advantage of being very conformable. It easily stretches and is often used to line large molds. This tape is coated with a high temperature resistant silicone adhesive system on one side.

**Features and Benefits**

- Excellent release characteristics
- Low friction surface
- Operational and dimensionally stable from –100°F (-73° C) to +500°F (+260° C)
- Chemical resistant
- Abrasion resistant

**Physical Properties**

Product Number	Backing Thickness (mil)	Breaking Strength (lb. / inch of width)	Adhesion (oz. / inch of width)	Elongation (%)	Dielectric Strength (V / mil)
PC SKIVED-3S	3	15	28	300	1000
PC SKIVED-5S	5	22	26	300	1500
PC SKIVED-10S	10	55	26	300	1200+

These product properties are suggestive and all products can be customized or converted to fit specific application requirements. Please contact us to discuss your unique application needs.